


30W 2.0 COMPACT BLUETOOTH SOUNDBAR



MODEL: GDSBT30CS

USER MANUAL



Goodmans

1 Welcome



2 30W 2.0 Compact Bluetooth Soundbar

- 2.1 In The Box
- 2.2 Front View
- 2.3 Side View
- 2.4 Rear View
- 2.5 Remote Control

3 Quick Setup

- 3.1 Power On/Off and Function Selection
- 3.2 Auto Power Off
- 3.3 Adjusting The Volume

4 Operation

- 4.1 Selecting LINE IN
- 4.2 Selecting AUX IN
- 4.3 Selecting Bluetooth

5 Troubleshooting

6 Technical Specifications

7 Customer Support

1 Welcome



Thank you for choosing this Goodmans product. We've been making electronics for the British people for 70 years. Each of our projects has been carefully designed to be great at what it does and this one is no exception. We hope you enjoy your new 30W 2.0 Compact Bluetooth Soundbar

2 Your 30W 2.0 COMPACT BLUETOOTH SOUNDBAR

2.1 In The Box

Carefully remove your 30W 2.0 Compact Bluetooth Soundbar from the packaging.

Inside the box you will find:

- 30W Soundbar
- Power Adaptor
- Quick Start Guide
- Guarantee Booklet
- 3.5mm Line-in Cable
- 3.5mm To RCA Cable
- RCA To RCA Cable
- Remote Control
- Wall Mount Kit

If any of these items are missing, contact customer support.

Visit: www.goodmans.co.uk/support



Mains Power

Your 30W Soundbar requires a mains supply of 230-240V AC ~ 50Hz.

Please ensure that your mains supply is compatible before use.

Disconnect the Power Cord from the mains when not in use.

Position of 30W 2.0 Compact Soundbar


Place on a flat, stable surface that is not subject to vibrations. Avoid the following locations:

- Where it is exposed to direct sunlight
- Where it is close to heat radiating sources
- Where the humidity is high and ventilation is poor
- Where it is dusty



2.2 Front View

A SPEAKER



2.3 Side View

B POWER

Press to power soundbar on or off.

C SOURCE

Press to select input.

D VOLUME

Press to decrease the volume.

E VOLUME


Press to increase the volume.

F BLUETOOTH

Press to pair the Bluetooth device with soundbar after access to BT mode.

G LINE IN SOCKET

Connect external audio sources with a 3.5mm audio cable.




2.4 Rear View

H AUX INPUT SOCKET

Connect external audio sources with RCA audio cable.


I DC MAINS INPUT SOCKET

Connect external mains adaptor to this socket.





2.5 REMOTE CONTROL









- J** POWER
Press to turn on/off.
- K** SOURCE
Press to select BT/LINE IN/AUX mode.
- L** DSP PRESETS
Press to access to Music/Movie/Voice mode.
- M** TREBLE
Increase or decrease the treble settings.
- N** In BT mode
Press to Skip/Back/Play/Pause/Stop the track.
- O** MUTE
- P** BASS
Increase or decrease bass settings.
- Q** VOLUME
Increase or decrease the volume.

3 Quick Setup



3.1 Power On/Off and Function Selection

1. This 30W 2.0 Compact Bluetooth Soundbar is supplied with a mains adaptor.
To connect the power insert the small end in the rear of the unit.
2. Insert the UK plug into a household power socket, and switch the power on.
3. Press the  button to turn the unit on.
4. Press the  button to select Bluetooth/Line in/Aux mode



3.2 Auto Power Off

If no audio signal is continuously detected from the selected mode for more than 170 minutes, the unit will power-off automatically.



3.3 Adjusting the Volume

Press the + button or - button in the side panel of the soundbar to adjust the volume to a comfortable level.










4.1 Selecting LINE IN

1. Press the  button in the side panel of the soundbar or alternatively press the STANDBY button on the remote control, so that the blue LED is illuminated.
2. Press the  button and select LINE IN mode or press the LINE IN button on your remote control.
3. Adjust volume to the desired level.

4.2 Selecting AUX IN

1. Press the  button in the side panel of the soundbar or alternatively press the STANDBY button on the remote control, so that the blue LED is illuminated.
2. Press the  button and select AUX IN mode or press the AUX button on your remote control.
3. Adjust volume to the desired level.

4.3 Selecting Bluetooth

1. Press and hold the  button on the unit or alternatively press the STANDBY button on the Remote Control.
2. Press the  button and select Bluetooth mode or press the BT button on the Remote Control to switch Bluetooth mode.
3. Press the  button on the unit .The blue light will flash quickly.
4. Use the controls on your Bluetooth device to select (GDSBT30CS) in your Bluetooth settings to pair. If your device requests a password, enter the "0000" . Refer to your device's user manual for instructions on pairing and connecting Bluetooth devices.

5 Troubleshooting



Problem	What to do
Soundbar does not respond (no power).	Check the mains power cable and make sure it is plugged into a suitable power outlet. Check that the mains power supply is switched on. Connect the power to a different power outlet.
No sound.	Check the Soundbar volume control is not at minimum. Check that the Soundbar is not set to MUTE. If you are connecting to the Soundbar using a headphones port on your external audio device then check the volume is turned up on that device.
The Remote Control does not work.	Replace the battery. Make sure there are no obstacles obscuring the Soundbar.
No sound in Bluetooth mode.	Check that the Soundbar is Paired with a Bluetooth device. If prompted enter the code '0000'.

6 Technical Specification

Power Supply	AC 230V,50 HZ.
Power Source of Remote Control	DC 3V, 1 x CR2025 Battery (supplied)
Power Consumption	< 30W
Audio Power	Left Channel 15W Right Channel 15W
Impedance	1 x Left Channel 18W 8Ω 1 x Right Channel 18W 8Ω

7 Customer Support

Our customer service team is available for technical or guarantee support. Visit www.goodmans.co.uk/support