


# Goodmans



## GCE4000PS2

2 x 7" LCD Monitor for Slim PS2

## Instruction Manual

[www.goodmans.co.uk](http://www.goodmans.co.uk)











## TABLE OF CONTENTS:

TABLE OF CONTENTS	Page 1
PACK CONTENTS	1
IMPORTANT NOTES	2
CONTROLS AND ADJUSTMENTS	4
INSTALLATION	4
CONNECTIONS	6
OPERATION	8
TROUBLE-SHOOTING	9
SPECIFICATIONS	9

## PACK CONTENTS

- |   |  |
|---|--|
| <ul style="list-style-type: none"> <li>a. 2 x 7" LCD Monitor</li> <li>c. 1 x AV Adapter cable</li> <li>e. 1 x Carry Bag</li> <li>g. 2 x Monitor Head-Rest Straps</li> </ul> | <ul style="list-style-type: none"> <li>b. 2 x PS2 Game Controller</li> <li>d. 1 x Cigarette Lighter Adapter</li> <li>f. 1 x Pouch For Mini PS2</li> <li>h. 1 x Instruction Manual</li> </ul> |
|---|--|

<p>a. 7" LCD Monitor</p> 	<p>b. PS2 Game Controller</p> 	<p>c. AV Adapter Cable</p> 	<p>d. Cigarette Lighter Adapter</p> 
<p>e. Carry Bag</p> 	<p>f. Pouch For Mini PS2</p> 	<p>g. Monitor HeadRest Straps</p> 	<p>h. Instruction Manual</p> 

## IMPORTANT NOTES

- To ensure proper ventilation and proper operation please ensure that the slots and openings are never blocked
- Keep the unit away from naked flame source
- Never expose the unit to moisture
- This unit is designed for negative ground 12V DC operation only. The equipment can be used safely, if the negative terminal is connected to the vehicle metal work.
- There are no user serviceable parts inside, therefore refer all servicing to qualified service personnel.
- Never take the monitor or cigarette adaptor apart as this could lead to an electric shock.
- When installing the unit ensure that it is placed away from any sources of heat, for example, car heater/hot air blower. Failure to observe this may result in a reduced lifetime for the components
- THIS KIT WILL ONLY FUNCTION WITH THE SLIM/MINI PS2.
- When Cleaning ensure that the unit is disconnected from the cigarette lighter socket

### IMPORTANT NOTE

**When positioning the unit please ensure that it does not interfere with the driver of the car and is not in the sight of the driver. Failure to follow this warning can result in the driver being prosecuted for driving without due care and attention**


## Important Health Warning

### Photosensitive Seizures

A very small percentage of people may experience a seizure when exposed to certain visual images, including flashing lights or patterns that may appear in video games. Even people who have no history of seizures or epilepsy may have an undiagnosed condition that can cause these “ photosensitive epileptic “ while watching video games.

These seizure may have a variety of symptoms, including lightheadedness, altered vision, eye or face twitching, jerking or shaking of arms or legs, disorientation, confusion, or momentary loss of awareness. Seizures may also cause loss of consciousness or convulsions that can lead to injury from falling down or striking nearby objects. Should anyone exhibit any of these symptoms, stop playing immediately and consult a doctor.


## Controls and adjustments



- |                                    |                                   |
|------------------------------------|-----------------------------------|
| 1. Power LED                       | 7. Right Audio Input Socket (Red) |
| 2. Power On/Off Button             | 8. Headphone Socket               |
| 3. Volume Control                  | 9. DC Input Socket                |
| 4. Brightness Control              | 10. Monitor Port                  |
| 5. Video Input Socket (Yellow)     | 11. Remote Sensor                 |
| 6. Left Audio Input Socket (White) |                                   |

## Installation

1. Insert the thin mounting strap as shown in steps 1,2 and 3.



2. Pass the thick strap underneath the thin strap as shown in step 4.



3. Pass the bottom of the strap under the headrest and the other end over the top and attach using the velcro as shown in step 5 and 6..



4. Use the clip to fasten the thin mounting strap (as shown in step 7).



5. Insert the mini PS2(not supplied) into the pouch. The pouch can then be secured using the supplied strap (steps 8 and 9 show an example of how to secure the PS2 in position. Please modify these steps in accordance with your vehicle so that the PS2 is attached securely without causing an obstruction to the driver of the vehicle).



## Connections

1. Connect the Cigarette Adapter's output plug with the tag-"PS2 - 8.5 V DC" into the Mini PS2 as shown in step1.



2. To Connect the monitors to the Mini PS, use the cable with RCA plugs (normally yellow, red and white) supplied with the Mini PS2 as shown in the photo to the right.

Insert the black port of the Mini PS2's AV adapter into Mini PS2 as shown in step 2



3. Connect the RCA male plugs of Mini PS2 cable into the RCA female sockets of AV adapter cable as show in step 3.

4. Plug the two groups of male RCA plugs into the two 7" LCD Monitors as shown in step 4.



5. Insert the two DC 12V output plugs with the tags "Monitor -12V" on the cable of the Cigaretter Lighter Adapter into the Monitors as shown in step 5.

6. Plug the Cigarette lighter adapter into the Cigarette lighter socket in car as shown in step 6.



7. Plug the game controllers into Mini PS2(as shown in steps 7 and 8).





# Operation

## **Power On/Off**

After completing all connections press the POWER ON/OFF button on the monitors to turn on. To turn off press the POWER ON/OFF button again

## **Volume Control**

To adjust the volume level, use the VOLUME CONTROL on the monitors.

## **Brightness Control**

To adjust the brightness level of the screen, use the BRIGHTNESS CONTROL on the monitors.

## **Headphones**

To listen using headphones, insert the plug from the headphones into the HEADPHONE SOCKET. The sound from the monitors speakers will be turned off automatically.

## Troubleshooting

Symptom	Possible Cause	Possible Solution
No Power	•Power Cable Not Connected	•Ensure that all connections have been made correctly
No Picture	•Monitor not turned on  •Brightness is turned down  •Audio/Visual cable not connected	•Turn the monitor on using the POWER ON/OFF button  •Increase the brightness using the BRIGHTNESS CONTROL  •Ensure that all connections have been made correctly
No Sound	•Headphones have been inserted.  •Volume is turned down  •Audio/Visual cable not connected	•Remove the headphones from the HEADPHONE SOCKET.  •Increase the volume level using the VOLUME CONTROL  •Ensure that all connections have been made correctly

## Specifications

TV System	PAL
Screen Size	7"
Power Supply(Monitors)	DC 12V
Power output(for PS2)	DC 8.5V
Power Consumption(Monitors)	12 Watts
Operating Temperature	5~40 Centigrade
Storage Temperature	-20~60 Centigrade
Operating humidity	10~75%
Weight(Single Monitor): (All components in bag):	0.54kg 7.56kg
Dimensions(Unit): (Bag):	270 x 150 x 37.5mm 420 x 195 x 130 mm