

WANT TO KNOW MORE?

The full User Manual is available online at:




www.goodmans.co.uk/support

BLUETOOTH SPEAKER


Model: GDBTSPK22BLK
GDBTSPK22CON

QSG-MAR17

Goodmans BLUETOOTH SPEAKER




GETTING STARTED



- a Connect to a USB power source to charge
- b Red LED will light when charging
- c When charging is complete red LED will turn off
- d Ensure unit is fully charged before first use

CONNECT USING BLUETOOTH



- a Turn the speaker on using the switch on the back.
- b The LED will flash blue.
- c Open the Bluetooth controls on your device and select GDBTSPK22 from the list.
- d The speaker will connect automatically.
- e Press and hold the control buttons to change volume. A quick press will change track.
- f For a non Bluetooth source, you can connect via 3.5mm jack cable (not supplied).

快速指南
尺寸：93x110mm
160g书写纸
双面单黑印刷