


Goodmans

GCR1885DAB

Digital Radio

User Guide



IMPORTANT: Please read all instructions carefully before use and keep for future reference.

Introduction


Thank you for buying this Goodmans digital radio, which also features an FM radio and auxiliary input connection.

You may already be familiar with using a similar unit, but please take time to read these instructions. They are designed to familiarise you with the unit's many features and to ensure you get the very best from your purchase.


Safety is important

Use of any electrical equipment should be undertaken with care. Please read the safety section on pages 22 to 23 before using this Digital Radio. This appliance is for household use only.

What's in the box?



Digital Radio - main unit



Power Adaptor



Quick Start Guide




Remote Control

The above images are for illustrative purposes only and may differ to the items supplied.


Contents

01 Your Digital Radio 4	07 AUX and Headphones 19
02 What is Digital Radio? 6	08 Troubleshooting 20
03 Getting Started 7	09 Specifications 21
04 Using DAB Radio 11	10 Warnings 22
05 Using FM Radio 13	11 Guarantee 24
06 Setting the Alarms 18	


Front view



Rear view



Remote control



What is Digital Radio?

DAB (Digital Audio Broadcasting) is the next generation of radio. DAB was developed in Europe by a consortium of broadcasters and manufacturers.

DAB uses digital compression techniques to transform the source material, i.e. music and speech, into digital computer code before it is transmitted. The computer code consists of electronic 'ones and zeros' called binary digits or bits. The binary code is then multiplexed or grouped together to create a superior signal, when compared with the older analogue system, with the following key benefits:

- **Near CD quality sound.**

Because DAB is binary coded, the receiving equipment is only expecting to receive a series of ones and zeros, so any other interference is ignored, resulting in very high quality audio.

- **Interference free reception.**

Analogue systems suffer from an effect called 'multipath distortion'. This is caused because radio waves do not behave in an orderly fashion, but bounce and reflect off buildings and mountains etc. DAB sees this as an advantage and uses the direct and reflected signals to actually reinforce the end result.

- **No need to re-tune.**

A single DAB frequency can be used to cover the whole of the UK, so solving many of the problems experienced with the earlier analogue system.

- **Scrolling text**

Broadcasters can transmit text to your radio. This way you can read the name of the DJ, artist, song title or any other information that is broadcast.

- **DAB coverage**


Check your local coverage at www.ukdigitalradio.com, to check if you are in a DAB broadcast area.

1

Fitting Batteries in the main unit

Alkaline batteries are recommended for best performance.

Referring to the diagram below, slide off the battery compartment lid and fit six type AA batteries into the battery compartment, observing the polarity shown in the compartment;.

**Battery Disposal**

Dispose of used batteries with regard to the recycling regulations in your area.

DO NOT short circuit batteries or throw them into water, general rubbish or in a fire.

Weak batteries can leak and damage the radio. Replace them in good time!

2


Connecting Power

Before connecting power to the Digital Radio, check that the mains voltage on the rating plate of the AC Adaptor is the same as the voltage in your area.


Plug the power connector on the AC Adaptor lead into the DC IN connector on the rear panel of the Digital Radio, see below.

Plug the AC Adaptor into the wall socket and switch the mains power on.

The unit is now ready for use.



Connect power socket here




3

Power Control

To turn the radio on:

- 1 Slide the POWER ON/OFF switch on the rear panel to the ON position.
- 2 The radio will switch on.



Set POWER ON/OFF switch to ON


To set the radio to Standby:

- 1 Press the **STANDBY** button on the Digital Radio front panel or on the Remote control.
- 2 The radio will set to standby. The clock will continue to run in Standby mode.


4

Remote Control Battery**Before first Use**

To prepare the remote control for first use, pull out the safety strip to activate the battery, see below.

**Replacing the battery**

When replacing the battery in the remote control, refer to the diagram below right.



- ❶ Press the catch across.
- ❷ While holding the catch, open the battery door.
- ❸ Fit the battery observing polarity as shown. When replacing the battery, use only the same CR2025 type specified

5

Setting the Clock


The clock on your radio will be automatically set when first used from the time signal broadcast with digital radio stations.

If a digital station is not available, the clock may be set manually via the Setting menu, see later.

6

Initial scan

When you turn your radio on for the first time the scanning display will be shown while the scanning process takes place, see example below.



Progress bar

The radio scans for all usable stations (full scan) and stores them alphanumerically: 1 Radio, 2 Radio, AA Radio, AB Radio... and so on.

The initial scan will take a few minutes. After the scan completes, the clock will be set and the radio will play the first station in the sequence.

To browse for another digital station

- ❶ Press the ◀ or ▶ Buttons repeatedly on the Digital Radio or on the Remote control.
- ❷ The stations in the station list will be displayed in sequence.
- ❸ Press the buttons until you find the station you want to listen to.
- ❹ Press the **SELECT** button to select the displayed station.
- ❺ After a short delay, the radio will tune to the station.

Adjusting The Volume**To increase the volume:**

- ❶ Press the **VOL +** Button to increase the volume.
- ❷ The volume level will increase.

To decrease the volume:

- ❶ Press **VOL-** to decrease the volume.
- ❷ The volume level will decrease.

The volume is adjusted the display will change to show the current volume setting on a bargraph.

Selecting Input Mode

Your Digital Radio has three input modes:

- DAB
- FM
- AUX

- ❶ Press the MODE button repeatedly to cycle through the modes.
- ❷ Stop when displaying the mode you want to use.

DAB Scanning

When you first turned on your radio it scanned the DAB band for available stations. The station services found were then stored in your radio's memory.

You can re-scan the band at any time if you move to a different area or just to refresh the stored list of available stations.

DON'T FORGET!

On some occasions, when moving to a different area, re-scanning may not fully update the station list. In this case it may be necessary to reset your radio as described under Factory Settings.

To scan for DAB stations manually:

- ❶ Select the DAB mode.
- ❷ Press the **SCAN** button.

The scanning process will take a few minutes. The number of services found

during the scan will be shown at the right side of the display.

After the scan, the radio will re-tune to the last station playing if it is available. Alternatively, you can continue to browse for an other station as described on the previous page.

Scanning Progress bar Number of stations found

DAB (and FM) presets

Your radio can store up to 10 of your favourite stations as presets on both the DAB and FM bands for quick recall.

To store a preset:

- ❶ Tune to the station you want to store as a preset.
- ❷ Press and hold the **PRESET** button.
- ❸ 'Preset Store' will be displayed.
- ❹ Press the ◀ or ▶ Button repeatedly to find the preset number where you want to store the selected station (1 to 10). If the preset position does not have a station currently stored it will display '(Empty)'.
- ❺ Press the **SELECT** button to confirm you want the station in the preset number indicated on the display.

To recall a preset

- ❶ Press the **PRESET** button briefly.
- ❷ Press the ◀ or ▶ Button repeatedly to find the preset number you want to play.
- ❸ Press the **SELECT** button briefly to play the station stored in the preset position.

- ④ The radio will re-tune and the stored station will be displayed.

DAB Display Modes

Display Mode Options

The bottom line of the display can be set to show different items of information that may be transmitted by a DAB station.

Each press of the **INFO** Button steps through the available options.

- DLS (Dynamic Label Segment)
- Signal Strength:
- Programme Type:
- Multiplex Name:
- Signal Error Rate
- Bit Rate:
- Time And Date

DON'T FORGET!

Some stations may not broadcast all of these options.

To choose the information to display:

- ① While playing a digital radio station, press the **INFO** button repeatedly to display the required information.

The full range of display options are described below.

DLS (Dynamic Label Segment):

This is a scrolling message giving real time information - song titles, news headlines, and so on.

Signal Strength: This setting will display a signal strength bargraph. The longer the bar graph, the stronger the signal. Setting the display to show signal strength is useful when setting up the aerial for the strongest signal.

Programme Type: This describes the style of the programme being broadcast.

Multiplex Name: DAB Digital radio stations are broadcast in multiplexes. Each multiplex is a bundle of radio station transmitted in a single frequency. There are national and local multiplexes; local ones contain stations specific to your area. This option displays the name of the multiplex name that contains the station you are listening to. Multiplex Number/Freq: This option will display the multiplex number and frequency that contains the station you are listening to.

Signal Error Rate: This option will display the level of signal errors in the current broadcast. The lower the number, the better the quality of the signal.

Bit Rate: DAB allows broadcasters to vary the BIT RATE (or the amount by which an audio signal can be compressed) depending on the type of broadcast. This enables the amount of stations on a multiplex to be maximised. Speech and News are often broadcast at a lower Bit Rate; music needs a higher Bit Rate for good fidelity.

Time And Date: Time and date are updated by broadcasted information.

DAB Settings Menu


Your Digital Radio has additional features and options available through the Settings Menu.

A complete map of the menu is shown below.

To enter the DAB Settings Menu

- ❶ Set to DAB mode.
- ❷ Press and hold down the **INFO** Button for a while.
- ❸ Press the ◀ or ▶ Button to scroll through the available options until the required option is displayed.

- ❹ Press the **SELECT** button to confirm your choice and enter the sub-menu.
- ❺ Press the ◀ or ▶ Button to move to the required option in the sub-menu.
- ❻ Press the **SELECT** button to confirm your choice
- ❼ Press the **INFO** button to move backwards through the menu,



Choose the 'System' menu option to open the sub-menu of system options shown on the menu map.

Details of the DAB Settings Menu

Autoscan: Select Autoscan to re-scan the entire DAB band and refresh the station list.

Manual Tuning: Manual tuning enables you to search the band manually by pressing the **or** button to step through the multiplex numbers and check if any have usable signal strength on a bargraph display. Manual tuning is not necessary in normal operation where scanning will have automatically established a station list of all usable stations.

More details of the System

Sub-menu options:

Sleep: Select this option to set a sleep time in the range 15-90 minutes. When a sleep time is set, the radio will set To Standby after the sleep delay time.

Choose 'Sleep Off' to cancel sleep mode.

Alarm: Select this option to set alarm times and activate one or both of the dual alarms.

More details of alarm setting in the 'Using Alarms' section.

Time: Select the Time option to set the clock manually. This may be useful if you are in an area where it is not possible to receive digital radio broadcasts.

Within the Time menu options you can change the clock display format between 12 and 24 hour, choose whether the clock should set from the DAB time signal (Auto update) and to change the format of the time and date display.

Display Setting: Select "Display set" then the "Active Backlight" sub-option to change the backlight brightness.

- ❶ Press **◀** or **▶** to adjust the brightness level.
- ❷ Press **SELECT** to enter the Standby Backlight sub-option.
- ❸ Press **◀** or **▶** to adjust the brightness level during Standby Mode.

Factory Reset: Select the 'Yes' sub-option to reset all the settings of your radio to the original factory settings.

The station list will also be cleared and any stored preset memories will be erased.

After a factory reset the radio will re-scan the band and renew the station list.

SW Version: This option will display the version number of the control software currently installed in your radio.

Listening To FM Radio

Your radio can also receive FM band radio stations

To change to FM band:

- 1 Press the **MODE** button to switch to FM mode.

To auto-tune to FM stations:

- 1 Press the **SCAN** Button or
- 2 Press and Hold the or button to search up or down for the next station in the band.

The radio will search and the tuning frequency will be displayed whilst searching. When a usable station is detected the radio will stop tuning and play the station.

If RDS data is present, the station name and scrolling radio text will be displayed.

If RDS data is not present, the tuned frequency will be displayed.

To manually tune to FM stations:

Each press of the ◀ or ▶ Button causes the radio to retune to -50 kHz or +50 kHz about the current tuned frequency respectively.

- 1 Press the ◀ or ▶ Button to tune the band in 50 kHz steps.
- 2 Repeat until the required tuning is achieved.

Stereo/Mono Reception


You can set your radio to switch automatically between stereo and mono FM reception (Stereo allowed) or to receive in mono only (Forced mono).

Setting to **Forced mono mode** may improve sound quality in areas where a weak aerial signal results in a high level of background noise.

- 1 Press the **MENU** button
- 2 Press or button until 'Audio Setting' displayed.
- 3 Press the **SELECT** button to go into Audio Setting.
- 4 Press the ◀ or ▶ Button to switch between the options of Stereo or Mono reception.
- 5 Press the **SELECT** button to confirm the selection
- 6 Press the **MENU** button again to exit the menu.

FM Display Modes

The bottom line of the display can be



switched to show different items of information that may be transmitted with an FM station.

The range of display options is shown below.

To change the display mode:


- ❶ Press the **INFO** button repeatedly to change the information displayed while playing an FM radio station.
- ❷ The full range of display options are shown below. Some stations may not broadcast all of these options.

FM Settings Menu

There are also some menu settings that are specific to FM radio operation. These settings may be changed through the Settings Menu.

To enter the FM Settings Menu:

- ❶ Set to FM mode.
- ❷ Press the **MENU** button.



A map of the menu is shown below, left. The menu is navigated in the same way as the DAB Settings Menu.

More Detail of the FM Settings Menu Options:

Scan Setting: With this menu option you can set the scanning sensitivity of the FM radio to two different levels - 'Strong stations only' or 'All stations'.

Setting to 'Strong stations only' will exclude weaker stations resulting in a quicker scan.

If you set to 'All stations' the scan will stop at every station detected, even if the signal is weak.

Audio Settings: This option enables you to set the radio to receive FM in Auto mode (Mono/Stereo) or in Mono only. This may be useful if the signal is weak and the broadcast is noisy.

System Settings:

Allows you to set the following:

- Tone Settings
- Sleep Settings
- Display Settings
- Time Settings,
- Perform a Factory Reset
- View the Software Version.

Tone Settings: Sets the Bass volume & Treble volume.

Sleep Settings: Select this option to set a sleep time in the range 15-90 min.

When a sleep time is set, the radio will set to Standby after the sleep delay time has elapsed.

Choose 'Sleep Off' to cancel the sleep mode.

Display Settings: Select "Display set" then the "Active Backlight" sub-option to change the backlight brightness

- ❶ Press the ◀ or ▶ Buttons to adjust the brightness level.
- ❷ Press **SELECT** to enter the Standby Backlight sub-option.
- ❸ Press the ◀ or ▶ Buttons to adjust the brightness level during Standby Mode.

Time Setting: Select the time option to set the clock manually.

Factory Reset Setting: Select the 'Yes' sub-option to reset all the settings of your radio to factory original settings.

The station list will also be cleared and any stored preset memories will be erased.

After a factory reset the radio will re-scan the band and renew the station list.

SW Version: This option will display the version number of the control software currently installed in your radio. This will be helpful to a technician who is servicing the radio.

Setting The Alarms

You can set two completely separate alarm times (ALARM 1 and ALARM 2) and activate either or both of them to wake you with a buzzer or radio.

The alarms are set from within the 'Alarm' option of the Settings Menu.

DON'T FORGET!

You must complete all the settings before leaving the menu or your changes will not be saved.

Set the alarm as follows:

DON'T FORGET!

Alarm settings cannot be changed when set to Standby.

- ❶ Switch on the radio.
- ❷ Press the **ALARM** button on front panel.
- ❸ 'Alarm Status Set' will appear on the display.
- ❹ Press the **SELECT** button (**NOT** 'SELECT Control') to begin setting Alarm 1, or
Press the button before selecting to choose Alarm 2 setup.
- ❺ Alarm 1 Wizard is now displayed.
- ❻ The alarm is now to be set in the sequence shown right.

DON'T FORGET!

Press the **MENU** Button at any time to exit alarm setting, leaving the settings unchanged.


To make a change to a setting:

- ❶ Press the ◀ or ▶ Button to scroll through the options available for a setting (or times when clock setting).
- ❷ When you have finished changing a setting, press the **SELECT** button to confirm the setting and move to the next setting in the sequence.
- ❸ Repeat the previous two steps to change each setting as required.

When changing the Alarm radio preset setting, wake to the last station you played before setting the radio to Standby.

Saving the alarm settings

Your alarm settings are automatically saved when you complete the last setting and press the 'SELECT control'.



Setting the Alarms

06

After you have set the alarm with your required time and wake-up mode, set the radio to Standby. If the alarm is active, the alarm symbol will show on the display .

Setting the Alarm to Wake You

To set the alarm to wake you:

- 1 Check that the Alarm symbol is displayed. If not, set the Alarm(s) On as described in the 'Setting the Alarms' section on the previous page.
- 2 Set the radio to Standby (or set the SLEEP function).

- 3 The radio will switch off and the time and the Alarm Symbol will be displayed

When the alarm sounds

To switch off the alarm:

- 1 Press the **POWER ON/OFF** Button or the **ALARM** Button.
- 2 Press the ◀ or ▶ Button to switch between Alarm 1 or 2.
- 3 Press **SELECT**
- 4 Press the ◀ or ▶ Button to select OFF.


AUX and Headphones

07

Auxiliary input

There is an jack socket on the rear panel (labelled AUX IN) to listen to an external audio player for example through the radio. The output cable from the external audio player must be terminated in a 3.5 mm stereo jack plug.

- 1 Connect the external audio player cable to the (not supplied) to the AUX IN socket on the rear panel.
- 2 Press the **MODE** button to switch the input to AUX. (DAB/FM/AUX).




Headphone output

There is a 3.5 mm jack socket on the back panel of the radio labelled with a headphone symbol.

This output is suitable for a set of headphones to be connected for private listening.

When the headphone jack is inserted, the speakers in the main unit are disconnected.



Problem	Possible Cause	What to do
No sound	<ol style="list-style-type: none">1. Volume may not be adjusted.2. Headphones are connected.3. Power is not correctly connected.	<ol style="list-style-type: none">1. Increase the Volume level.2. Disconnect your headphones if they are connected to the headphone output.3. Check and connect the power properly.
The radio does not operate when you press any buttons	<ol style="list-style-type: none">1. Electrostatic discharge.	<ol style="list-style-type: none">1. Turn off the unit, disconnect the main power, and reconnect after a 60 seconds
Radio poor reception	<ol style="list-style-type: none">1. Weak radio signal.2. Interference caused by ther electrical equipment.	<ol style="list-style-type: none">3. Extend and aim the aerial for the best reception possible.4. Keep the radio away from other electrical equipment where possible.

Power Supply, main unit	<ul style="list-style-type: none"> • DC 9V, 500mA via supplied 230VAC/DC Adaptor, 9V, 6 x 1.5V batteries type AA/UM03
Remote control	<ul style="list-style-type: none"> • 3V lithium battery type CR2025
Power Consumption	<ul style="list-style-type: none"> • 3W
Tuner Frequency Coverage	<ul style="list-style-type: none"> • DAB: 174 - 240MHz (BAND III) • FM: 87.5 -108MHz
Sensitivity	<ul style="list-style-type: none"> • -95 dBm typical
Headphone output	<ul style="list-style-type: none"> • 3.5 mm jack socket
AUX IN (audio)	<ul style="list-style-type: none"> • 3.5 mm jack socket

IMPORTANT: Due to continual revision and improvements to our products design, specifications are subject to change without notice.

WEEE



This Digital Radio is labelled in accordance with European Directive 2002/96/EG concerning used electrical and electronic appliances (Waste Electrical and Electronic Equipment - WEEE).

The guideline determines the framework for the return and recycling of used appliances.

Sound levels

Your hearing is very important to you and to us, so please take care when using this Digital Radio. It is strongly recommended that you follow the listed guidelines in order to prevent possible damage or loss of hearing.

Establish a safe sound level

Over time your hearing will adapt to continuous loud sounds and will give the impression that the volume has in fact been reduced. What seems normal to you may in fact be harmful. To guard against this **before your hearing adapts**, set the volume to a low level.

Slowly increase the level until you can hear comfortably and clearly and without distortion. Damage to your hearing is accumulative and is irreversible. Any ringing or discomfort in the ears indicates that the volume is too loud.

Once you have established a comfortable listening level, **do not increase the sound level**.

General Safety

This Digital Radio has been designed and manufactured to meet European safety standards, but like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

Do read these operating instructions before you attempt to use the Speaker System.

Do ensure that all electrical connections (including the mains adaptor, extension leads and interconnections between pieces of equipment) are properly made in accordance with the manufacturer's instructions.

Switch off and remove the mains adaptor when making or changing any connections.

Do consult your dealer if you are ever in doubt about the installation, operation or safety of your Digital Radio.

Don't continue to operate the Digital Radio if you are ever in doubt about it working normally, or if it is damaged in any way. Switch it off withdraw the mains adaptor from the mains and consult your dealer.

Don't remove any fixed covers as this may expose you to dangerous voltages.

Don't leave the Digital Radio switched On when it is unattended for long periods of time, unless it is specifically stated that it is designed for unattended operation or has a standby mode. Ensure other people in your household are conversant with the Digital Radio.

Don't obstruct the ventilation vents

on the Digital Radio, for example with curtains or soft furnishings.

Overheating will cause damage and shorten the life of the product.

Don't allow electrical equipment to be exposed to rain or moisture.

Store the Digital Radio in a clean, dry environment.

Do not use any cleaning solutions on the Digital Radio.

Electrical Safety

Read these electrical safety instructions carefully before connecting the power adaptor to the mains supply.

This Digital Radio is supplied with a mains adaptor which has been designed for indoor use only.

The mains adaptor is a sealed unit. There are no user serviceable parts inside and it does not require any electrical adjustments.

Do not attempt to open the mains adaptor.

If the mains adaptor becomes damaged, or fails to operate your Digital Radio, it must be replaced and disposed of in a safe and environmentally protective way.

The mains adaptor is designed to operate on 100 - 240VAC 50 - 60Hz supply. Connecting it to any other power sources may damage the mains adaptor and the Digital Radio.

This Digital Radio is guaranteed for twelve months from the date of original purchase. If any defect due to faulty materials or workmanship, contact the Goodmans Helpline. Have your receipt of purchase on hand.

The guarantee is subject to the following provisions:

- It is only valid within the boundaries of the country of purchase.
 - The product must be correctly installed and operated in accordance with the instructions contained in this User Guide.
 - This Digital Radio must be used solely for domestic purposes.
 - The guarantee will be rendered invalid if the Digital Radio is re-sold or has been damaged by inexpert repair.
 - The manufacturer disclaims any liability for incidental or consequential damages.
 - The guarantee is in addition to, and does not diminish, your statutory or legal rights.
-